

#### GUIDANCE FOR EMPLOYERS ON CONTROLLING **EXPOSURE TO RCS IN THE WORKPLACE**

## **GOOD PRACTICES FOR FINAL** TREATMENT (DRY OR WET) IN **CERAMICS AND CONCRETE**

This activity relates to dry or wet machining operations (e.g. grinding, sawing, drilling) of ceramic products containing crystalline silica.



#### **ACCESS**

- Restrict access to the working area to authorised personnel only.
- The work area and equipment should be clearly labelled.
- Traffic ways should be marked.



#### 🖎 DESIGN AND EQUIPMENT

- Enclose the machining station as much as possible.
- Provide local exhaust ventilation around the machining station with an inward airflow of typically at least 1 m/s at the point where the dust is generated. Refer to task guidance sheet 2.1.13.
- Consider the need for additional ventilation at the discharge of the machined parts and transfer points.
- Ensure air discharges from pneumatic systems do not interfere with the dust control measures.
- Design any enclosure in sections to allow easy access for cleaning and maintenance.
- Where possible, locate the work area away from doors, windows and walkways to stop draughts interfering with the ventilation and spreading dust.
- Provide an air supply to the workroom to replace extracted air.
- Keep ducts short and simple.
- Avoid long sections of flexible duct.
- Provide an easy way of checking the control is working, e.g. a manometer, pressure gauge or tell-tale (a small flag).
- Discharge extracted air to a safe place away from doors, windows and air inlets.
- You can recirculate clean filtered air into the workroom. Quantities of recirculated air should be in compliance with existing standards.

See for example:

hse.gov.uk/pUbns/priced/hsg258.pdf publikationen.dguv.de/dguv/pdf/10002/209-084.pdf



## MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

## **EXAMINATION AND TESTING**

- Obtain information on the design performance of the ventilation equipment from the supplier. Keep this information to compare with future test results.
- Visually check all equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Have the ventilation equipment examined and tested against its performance standard, at least once each year.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.





## GUIDANCE FOR EMPLOYERS ON CONTROLLING EXPOSURE TO RCS IN THE WORKPLACE

## CLEANING AND HOUSEKEEPING

- Clean your workplace and equipment on a regular basis.
- Deal with spills immediately.
- Use vacuum or wet cleaning methods.
- DO NOT clean up with a dry brush or using compressed air.

### **TRAINING**

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet
   2.3.4 and part 1 of the Good Practice Guide.

#### SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet 2.3.3.
- Employers should make sure that employees have all the means to perform the checklist given below.

# PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet 2.1.15 dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace personal protective equipment at intervals recommended by the manufacturer/supplier.

### **EMPLOYEE CHECKLIST**

system is switched on a product of a product	ou think there is coblem with your control equipment, are additional control asures are taken educe exposure to cirable crystalline a dust while the olem persists.	Clear up spills immediately. Use vacuum cleaning or wet cleaning methods for solids. Dispose of spills safely. Do not clean up with a dry brush or using compressed air. Use, maintain and store any respiratory protective equipment provided in accordance with instructions.	Check and implement the measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.
--	---	---	--

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during dry or wet machining operations on ceramic products containing crystalline silica.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to

apply all of the control measures identified in this sheet in order to minimise exposure to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Document on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.