

GOOD PRACTICES FOR BAG EMPTYING – SMALL BAGS

This sheet provides advice on emptying of small bags of products containing crystalline silica in a production unit, particularly those containing dry materials.


ACCESS

Restrict access to the work area to authorised personnel only.


DESIGN AND EQUIPMENT

- Ensure bag emptying equipment is fit for purpose.
- Enclose the bag emptying equipment as much as possible and keep it under negative pressure by using a local exhaust ventilation system – refer to task guidance sheet **2.1.13**.
- For small bags, the use of automatic or semi-automatic bag dumping stations is recommended for emptying the bags.
- Ensure workers tip the bag contents gently – never dump them. Bags should be emptied with the open end facing away.
- Bag crushing creates a lot of dust. Workers should roll up empty bags within the extraction zone.
- In order to dispose of empty bags without creating dust, drop them into a large plastic sack supported and held open by a metal frame. When it is full, seal the sack and dispose of it in a suitable waste skip. **DO NOT let the waste sack overflow.** Alternatively, use a compactor equipped with a dust extraction system or which is fully enclosed.
- Bag emptying equipment should be connected to a suitable dust arrestment system (e.g. bag filter/cyclone). A permanent dust extraction system is preferred, though a stand-alone mobile unit is acceptable.
- Bag emptying equipment should be designed for easy access to all parts for maintenance, unblocking and cleaning. Access panels should be interlocked or have trip devices where necessary to prevent persons accessing dangerous parts of machinery.

- Consider providing mechanical/pneumatic assistance with bag handling.
- Where possible keep bag emptying equipment away from doors, windows and walkways to prevent draughts affecting the performance of dust extraction systems.
- Provide a clean air supply to the workroom to replace extracted air.



Manual Bag Emptying



Automated Bag Emptying

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Visually check the cleaning equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- Deal with spills immediately.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.

- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|---|--|---|---|
| <input type="checkbox"/> Make sure the ventilation system is working properly. Make sure the dust extraction system is switched on and is working correctly before starting work. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Use handling aids when available. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| | | <input type="checkbox"/> Clean up work rooms using vacuum or wet cleaning techniques. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during small bag emptying operations.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR BAG EMPTYING – BULK BAGS

This sheet provides advice on how to empty bulk bags (big bags) of products containing crystalline silica in a production unit, particularly those containing dry materials.


ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure bag emptying equipment is fit for purpose.
- Enclose the bag emptying equipment as much as possible and keep it under negative pressure by using a local exhaust ventilation system – refer to task guidance sheet **2.1.13**.
- **Manual bag cutting is not recommended without the use of personal protective equipment.**
- For single trip bulk bags without inner liner, use bag emptying equipment featuring pyramidal cutting knives and a rubber membrane to seal off the bag bottom.
- For multiple trip bulk bags, a discharge system with vibrator plate should be used and this should be equipped with local exhaust ventilation.
- Where multiple trip bulk bags are used, which have inner liners, special dust-free outlet connection systems are available which have double ring seals and fully enclosed product discharge.
- In order to dispose of empty bags without creating dust, do not manually compress the empty bags. Instead, drop them into a large plastic sack supported and held open by a metal frame. When it is full, seal the sack and dispose of it in a suitable waste skip. **DO NOT let the waste sack overflow.** Alternatively, use a compactor equipped with a dust extraction system or which is fully enclosed.
- Bag emptying equipment should be connected to a suitable dust arrestment system (e.g. bag filter/cyclone)
- Bag emptying equipment should be designed for easy access to all parts for maintenance, unblocking and cleaning. Access panels should be interlocked or have trip devices where necessary to prevent persons accessing dangerous parts of machinery.

- Consider providing mechanical/pneumatic assistance with bag handling.
- Where possible keep bag emptying equipment away from doors, windows and walkways to prevent draughts affecting the performance of dust extraction systems.
- Provide a clean air supply to the workroom to replace extracted air.



MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Visually check the cleaning equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- Deal with spills immediately.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.

- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheets **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|---|--|---|---|
| <input type="checkbox"/> Make sure the ventilation system is working properly. Make sure the dust extraction system is switched on and is working correctly before starting work. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Use handling aids when available. | <input type="checkbox"/> Clean up control rooms using vacuum or wet cleaning techniques. | |
| | | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during bulk bag emptying operations.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR BULK ROAD TANKER LOADING

This activity covers bulk loading operations for road tanker transport of products containing crystalline silica, particularly those containing dry materials.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure the loading equipment is adequate and well maintained.
- Provide a loading bellow chute capable of extracting enough air to keep the loading point under negative pressure.
- The loading bellow should be connected to a suitable dust extraction system (e.g. a bag filter/cyclone).
- Make arrangements to discharge the air, which is displaced during loading of bulk products, so that it can not escape from the vessel.
- Provide where possible closed and depressurised transport equipment with adequate de-dusting equipment.
- Where possible, incline de-dusting ducts so as to avoid settling of dust. Ensure minimal internal wear on ducts by selecting wear resistant materials, using adequate duct dimensions and by avoiding sharp bends.
- Design ducts with appropriate internal diameter (increasing as one approaches the de-dusting system) in order to maintain adequate transport velocities and to prevent settling of dust.
- Try to avoid leakages as much as possible.
- Control cabins should have their own clean air supply, or may be fitted with forced air filtration.



MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Visually check the cleaning equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of the dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|---|--|---|---|
| <input type="checkbox"/> Make sure the loading equipment is working properly. Make sure the dust extraction system is switched on and is working. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Use handling aids when available. | <input type="checkbox"/> Clean up any control cabin using vacuum or wet cleaning methods. | |
| | | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during bulk loading operations for road tanker transport.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR BULK ROAD TANKER UNLOADING (BLOWING OFF)

This activity covers the discharge of silica sand and flour products from a road tanker into a storage silo, particularly dry materials.

ACCESS

Restrict access to the work area to authorised personnel only.


DESIGN AND EQUIPMENT

Road Tanker

- Limit the discharge rate to the design capacity of the receiving silo and dust extraction unit. Offloading pressures should be agreed with the silo operator.
- Tanker offloading pipes, connectors and seals must be designed to withstand the high air pressures and abrasion associated with blowing operations.
- Note that there will be a surge of air pressure as the last sand/flour is blown into a silo. Hence the need for constant supervision of offloading operations.

Customer silo

- Storage silos should be purchased only from reputable suppliers.
- Appropriate engineering design methods should be employed to ensure adequate structural strength.
- Engineering controls must be employed to prevent over-pressurisation of the silo while it is being filled. Ensure that the silos are equipped with pressure relief devices and high level alarms. They must also have dust extraction systems to remove and clean the displaced air.
- Silo dust extraction units must be fitted with filters that are appropriate to the particle size range of the product.
- Offloading pressures should be agreed with the tanker operator.
- Note that flour products have varying bulk density. Put in place procedures to ensure that silos are not overfilled.
- Silos should be equipped with a dust extraction system to prevent the emission of dust from the silo during tanker offloading.



- Pipework and ductwork should be designed to minimise shock losses (caused by bends, constrictions etc.); to minimise dead spots where material may accumulate and to facilitate easy clearing of blockages.
- Silo connection points should be located as close as possible to the delivery tanker parking area. This will eliminate the need for long lengths of flexible hose.
- Safe means of access should be provided to those parts of the silo requiring inspection and maintenance.

MAINTENANCE

- Maintain pipes/hoses, connectors and seals in good condition to reduce the likelihood of dust escaping during blowing operations.
- Dust extraction systems on silos must be maintained in accordance with manufacturers' instructions.

EXAMINATION AND TESTING

- A competent person should test the performance of dust extraction systems at least annually.
- Tanker drivers should check the condition of pipes/hoses and seals daily and obtain replacements as necessary.
- Any faults with the pipes/hoses/connectors and silo dust extraction systems must be reported as soon as possible so that remedial action can be taken.
- Put in place measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- The tanker offloading area should be kept clean and tidy.
- Clean your workplace on a regular basis.
- Deal with spills immediately.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.

- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Ensure procedures are in place to prevent overfilling of silos.
- Have a system to check that dust control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to check the effectiveness of control measures.
- Respiratory protective equipment (with the appropriate protection factor) may need to be worn when disconnecting the offloading pipe at the back of the tanker, when remedying any escape of dust or in the event control measures fail.
- Provide storage facilities to keep personal protective equipment clean when not in use. Replace this equipment at intervals recommended by suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|--|---|
| <input type="checkbox"/> Tanker drivers must supervise their offloading operations at all times. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Clean up spillages of sand and flour immediately, using wet cleaning methods. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. |
| <input type="checkbox"/> Agree offloading pressures with the customer. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Wear a dust mask when it is necessary to enter dusty areas in order to rectify any escape of dust, or in the event other control measures fail. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Check the condition of pipes, hoses and connectors daily. | | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on how to minimise the release of airborne dust when blowing off a road tanker of silica sand or flour.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR BULK UNLOADING

This activity covers bulk unloading operations for road (except road tankers), rail and water transport of crystalline silica containing materials, particularly dry materials. Sheet **2.2.4a** offers advice on unloading of road tankers.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure that all unloading equipment is fit for purpose and well maintained.
- When discharging dry products, install dust extraction systems in areas where dust may be emitted into the workplace air.
- Consider isolating the discharge area and keeping it under negative pressure. Alternatively, provide control rooms which are sealed and kept under positive pressure.
- The truck driver should remain in the cab of the truck during unloading with the doors and windows closed. Where possible, a HEPA filter should be incorporated in the cab's HVAC system.
- Design the size and shape of receiving hoppers so that they are appropriate to the capacity of the road haulage vehicles, rail wagons, grabs etc feeding them.
- Prepare offloading procedures. Ensure that hoppers and discharge areas are clearly labelled with their contents.
- **DO NOT discharge flour products in the open air; enclosed systems must be used.**
- See task guidance sheet **2.2.4a** entitled "Bulk Road Tanker Unloading" for advice on blowing off dry products from road tankers.

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.



EXAMINATION AND TESTING

- Visually check the cleaning equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of dust extraction equipment from the supplier. Keep this information to compare it with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- Deal with spills immediately.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how

to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

- Ensure that delivery drivers are provided with copies of offloading procedures and training on these as necessary.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Indicate the need for respiratory protective equipment to be worn using appropriate pictogram signs.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|--|---|---|---|
| <input type="checkbox"/> Make sure the unloading equipment is working properly. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Check and implement the measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Make sure the dust extraction system is switched on and is working. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |
| <input type="checkbox"/> Wear respiratory protective equipment (e.g. a dust mask) in areas where this has been deemed necessary. | | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during bulk unloading operations.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR CUTTING AND POLISHING CERAMIC AND STONE MATERIALS

This activity relates to the cutting of ceramic materials which may generate large quantities of airborne dust.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Dust control can be achieved by using wet cutting methods, which prevent fine dust from becoming airborne by trapping it in water.
- Ensure that water supplies are adequate and that they are maintained. Take precautions during cold weather against freezing.
- Take precautions to ensure the control of legionella and other biological agents. If the water used for wet cutting is recirculated, ensure that it is checked regularly with respect to pH value and contamination with micro organisms.
- The provision of appropriate drainage systems is essential when using water sprays and hoses.
- Ensure that electrical systems etc. have adequate protection against the hazards present in the working environment, including water and silica dust.
- Use cutting and polishing tools containing no crystalline silica.



MAINTENANCE

- Maintain the equipment as advised by the supplier, in efficient working order and good repair.

EXAMINATION AND TESTING

- Visually check the equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean the equipment regularly.
- Use vacuum or wet cleaning methods.
- **DO NOT clean up with a dry brush or using compressed air.**
- **DO NOT allow deposits of dust/debris to dry out before cleaning up.**

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Indicate areas where personal protective equipment must be worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.
- Risk assessment could be carried out to determine whether existing controls are appropriate.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Ensure that you follow your employer's safe working procedures. | <input type="checkbox"/> Look for signs damage, wear or poor operation of any of the equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Clean using vacuum or wet cleaning method. | <input type="checkbox"/> Check and implement the measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| | <input type="checkbox"/> Clean up the equipment after use. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on the cutting and polishing of refractory materials.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR FIRING (BISCUIT, GLAZE, FINAL, DECORATION) IN CERAMICS AND STONES

This activity relates to the firing of ceramic products in periodic or continuous kilns. The measures for biscuit firing, glaze firing, final firing or decoration firing are similar.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT


- Good thermal insulation should be applied.
- Local exhaust ventilation should be applied to the entry and exit points of a continuous kiln or to the door of a periodic kiln (to prevent vapour loss, contamination and dust emissions).
- Exhaust ventilation systems should be easily controllable, interlocked to the kiln heating controls and fitted with warning lights/alarms.
- **When feeding or onloading the kiln, avoid any friction of the products to be fired (design of transportation units).**
- Where possible, locate the work area away from doors, windows and walkways to stop draughts interfering with the ventilation and spreading dust.
- Provide an air supply to the workroom to replace extracted air.
- Provide an easy way of checking the control is working, e.g. a manometer, pressure gauge or tell-tale (a small flag).
- Discharge extracted air to a safe place away from doors, windows and air inlets.
- **Air recirculation is not recommended.**

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Obtain information on the design performance of the ventilation equipment from the supplier. Keep this information to compare with future test results.



- Visually check all equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Have the ventilation equipment examined and tested against its performance standard, at least once each year.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace and equipment on a regular basis.
- Deal with spills immediately.
- Use vacuum or wet cleaning methods.
- **DO NOT clean up with a dry brush or using compressed air.**

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace personal protective equipment at intervals recommended by the manufacturer/supplier.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Make sure the ventilation system is switched on and is working. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Clear up spills immediately. Use vacuum cleaning or wet cleaning methods. Dispose of spills safely. | <input type="checkbox"/> Check and implement the measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Make sure it is running properly; check the manometer, pressure gauge or tell-tale. | <input type="checkbox"/> Remove broken products immediately from feeding units. | <input type="checkbox"/> Do not clean up with a dry brush or using compressed air. | |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during firing of ceramic products containing crystalline silica. The firing process can be periodic or continuous.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to

apply all of the control measures identified in this sheet in order to minimise exposure to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Document on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR ISOSTATIC PRESSING (DRY) IN CERAMICS

This activity relates to the isostatic pressing of ceramic products containing crystalline silica. Dust is possible while filling the moulds and when removing them.

ACCESS


Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Control raw material spillage. Make sure the right amount of raw material is used for the mould e.g. by providing a gauge.
- Enclose the filling/unforming station as much as possible.
- Make the enclosure deep enough to contain equipment and materials.
- Keep the open area as small as possible – while allowing enough room for safe working. Use see-through panels and plastic strips to reduce the open area.
- The general airflow into the enclosure should typically be at least 0.5 m/s. The airflow towards the hood slots should typically be at least 1 m/s. Refer to task guidance sheet **2.1.13**.
- **DO NOT store items inside the ventilated area; they will obstruct the airflow. Ensure large items do not obstruct the work opening.**
- Where possible, locate the work area away from doors, windows and walkways to stop draughts interfering with the ventilation and spreading dust.
- Provide an air supply to the workroom to replace extracted air.
- Provide an easy way of checking the control is working, e.g. a manometer, pressure gauge or tell-tale (a small flag).
- Discharge extracted air to a safe place away from doors, windows and air inlets.
- You can recirculate cleaned and filtered air into the workroom, in quantities recommended by existing standards.

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.



©TECHNIKUM PROFESSUR FÜR KERAMIK, FEUERFEST UND METALLOKERAMISCHE VERBUNDWERKSTOFFE, TU BERGAKADEMIE FREIBERG

EXAMINATION AND TESTING

- Obtain information on the design performance of the ventilation equipment from the supplier. Keep this information to compare with future test results.
- Visually check all equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Have the ventilation equipment examined and tested against its performance standard, at least once each year.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace and equipment on a regular basis.
- Deal with spills immediately.
- Use vacuum or wet cleaning methods.
- **DO NOT clean up with a dry brush or using compressed air.**

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace personal protective equipment at intervals recommended by the manufacturer/supplier.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Make sure the ventilation system is switched on and is working. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Remove broken products immediately from the work area. | <input type="checkbox"/> Do not clean up with a dry brush or using compressed air. |
| <input type="checkbox"/> Make sure it is running properly; check the manometer, pressure gauge or tell-tale. | <input type="checkbox"/> Make sure that paper bags and other waste material aren't drawn into the ventilation duct. | <input type="checkbox"/> Put lids on containers immediately after use. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Make sure that large items do not obstruct the working opening. | <input type="checkbox"/> Clear up spills immediately. Use vacuum cleaning or wet cleaning methods for solids. For liquids contain or absorb with granules or mats or wash away with a lot of water. Dispose of spills safely. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during isostatic pressing of ceramic products containing crystalline silica.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Document on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR JUMBO BAGGING

This activity covers bagging operations for big (bulk) bags (500kg-1500kg) containing crystalline silica products, particularly dry materials.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure that bags and bag filling equipment are fit for purpose. When bagging flour products, the quality of bag stitching is crucial in preventing the emission of fine dust through the seams of the bags.
- The use of a bag with an inner plastic liner will help to reduce the emission of dust through bag seams.
- Use a bagging head in which the product passes down the centre and in which an annular ring is used for the purposes of dust extraction and for the removal of displaced air.
- The annular ring should be connected to a dust extraction unit (e.g. bag filter).
- Seal the bag collar onto the bagging head to prevent the escape of dust during bag filling. A strip of Velcro, a clamp or an inflatable bladder can be used for this purpose.
- Install bulk bagging equipment in a well-ventilated area. Outdoor installation (in an area protected from the rain) will help to reduce personal exposure to respirable crystalline silica by taking advantage of natural ventilation.
- When bagging flour products, consider the installation of a vibrator in the bagging head, to help loosen material from inside the bagging head prior to removal of each bag.
- When bagging flour products, consider the installation of a vibrating table beneath the bag in order to compact the material and improve stability during subsequent storage and transport.

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.



GUIDANCE FOR EMPLOYERS ON CONTROLLING EXPOSURE TO RCS IN THE WORKPLACE

EXAMINATION AND TESTING

- Visually check the equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of the dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Have the extraction equipment examined and tested against its performance standard, at least once each year.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.
- Store bags in a safe place and dispose of empty bags safely.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.

- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|--|---|---|---|
| <input type="checkbox"/> Make sure that the bagging machine is working properly. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica while the problem persists. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Make sure the dust extraction system is switched on and that it is working correctly. | <input type="checkbox"/> Make sure that bags are free of faults, especially the loops, inlet and outlet spouts and inner liner if used. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during the jumbo bag filling.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR MIXING OF MATERIALS


This sheet provides guidance on the design and use of equipment used for the mixing of products containing crystalline silica, particularly dry products.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure that mixers are fit for purpose and that they are well maintained.
- Enclose mixers as much as possible.
- Mixer lids and other access points should be sealed to prevent the escape of dust.
- All covers and access doors must be securely closed before starting the mixer.
- The mixer charging point should be enclosed and provided with local exhaust ventilation.
- Alternatively, local exhaust ventilation can be supplied at points inside the lid or rear of the mixer casing, so that there is a net influx of air through the charging point and into the mixer.
- All extraction systems should be designed so as not to draw excessive amounts of raw material from the mixer.
- When producing a dry mix, consider arrangements for dust-free discharge of mixed products. eg direct discharge to an enclosed conveyor system. Alternatively, provide local exhaust ventilation at the discharge point.
- Local exhaust ventilation systems must be connected to a suitable dust extraction unit.
- Where possible, mixer charging points should be located away from doors, windows and walkways to prevent draughts affecting the performance of local exhaust ventilation systems.
- Provide a clean air supply to the workroom to replace extracted air.



MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Visually check the cleaning equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- Store containers in a safe place and dispose of empty containers safely.
- Put lids on containers immediately after use.
- Deal with spills immediately.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Make sure the work area is well ventilated and that any dust extraction system is switched on and is working correctly. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. Dispose of spills immediately. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on dust control when mixing materials containing crystalline silica dust.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR PREPARATION IN CERAMICS

This activity relates to semi dry preparation of materials containing crystalline silica by different kinds of processes e.g. crushing in pan mills, circular feeders or roller mills, storage in sourcing houses, box feeders or silos and mixing of additives.

ACCESS

- Restrict access to the work area to authorised personnel only.
- The work area and equipment should be clearly labelled.

DESIGN AND EQUIPMENT

- Installation should have sufficient traffic paths to allow easy cleaning and maintenance.
- For machines and activities which are relevant concerning dust emission, dust extraction should be provided.
- The mixing in from silos (ashes, slag) should be sufficiently protected by enclosures.
- Where possible provide enclosure of silo discharge and dropping from conveyor belt.
- Design any enclosure in sections to allow easy access for cleaning and maintenance.
- Where possible, locate the work area away from doors, windows and walkways to stop draughts interfering with the ventilation and spreading dust.
- Discharge extracted air to a safe place away from doors, windows and air inlets.
- You can recirculate cleaned and filtered air into the workroom in quantities recommended by existing standards.

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.



EXAMINATION AND TESTING

- Obtain information on the design performance of the ventilation equipment from the supplier. Keep this information to compare with future test results.
- Visually check all equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Have the ventilation equipment examined and tested against its performance standard, at least once each year.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace and equipment on a regular basis.
- Deal with spills immediately.
- Use vacuum or wet cleaning methods.
- **DO NOT clean up with a dry brush or using compressed air.**

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace personal protective equipment at intervals recommended by the manufacturer/supplier.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Make sure the ventilation system is switched on and is working. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Clear up spills immediately. Use vacuum cleaning or wet cleaning methods for solids. Dispose of spills safely. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Make sure it is running properly; check the manometer, pressure gauge or tell-tale. | | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control during the semi dry preparation of materials containing crystalline silica by different kinds of processes.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to

apply all of the control measures identified in this sheet in order to minimise exposure to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Document on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR SMALL BAG FILLING – COARSE PRODUCTS

This activity covers bagging operations for small bags (15kg-50kg) with dry products containing crystalline silica. This sheet is only relevant to products in which the grains have not been ground down to flour, i.e. sand sized or coarser. The bagging of flours is covered in sheet **2.2.30b**.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure that bags and bag filling equipment are fit for purpose. The quality of the bags is crucial to preventing leakage of dust through the bag seams.
- Use bagging heads in which the product passes down the centre and in which an outer, annular ring is used for the purposes of dust extraction and for the removal of displaced air. The outer, annular ring should be connected to a dust extraction unit (e.g. bag filter).
- Ensure that bags are effectively clamped/sealed onto the bagging head during bag filling to prevent the escape of dust.
- Position the bagging head inside a dust extraction hood which is enclosed as much as possible.
- The dust extraction system serving the hood must have sufficient capture velocity to prevent the escape of dust emitted through the bag seams and dust discharged from the bagging head when the bag is removed. Refer to task guidance sheet **2.1.13**.
- Bags must be sealed shut as soon as they are removed from the bagging head. Bags with self-sealing valves are available or, alternatively, bag stitching or heat sealing techniques may be used.
- Consider mechanical/pneumatic assistance with bag handling.
- In automated bagging systems, the use of a carousel system enables many bags to be filled simultaneously at a very slow rate using a screw feed. When bags are filled slowly, less dust is emitted.



MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Visually check the equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of the dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.
- Store bags in a safe place and dispose of empty bags safely.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|---|---|--|---|
| <input type="checkbox"/> Make sure that the bagging machine is working properly. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Even if it is not normally necessary for you to wear a dust mask, it may be necessary for you to wear one temporarily in the event of a spillage or if other control measures fail. | equipment provided in accordance with instructions. |
| <input type="checkbox"/> Make sure that bags are free from defects, especially as regards valve construction. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica while the problem persists. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Use handling aids when available. |
| <input type="checkbox"/> Make sure that the dust extraction system is switched on and is working correctly. | | <input type="checkbox"/> Use, maintain and store any respiratory protective | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on dust control during the filling of small bags with coarse products.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.

GOOD PRACTICES FOR SMALL BAG FILLING – FLOURS/FINES

This activity covers bagging operations for small bags (5kg-50kg) with dry products containing crystalline silica.

This sheet is only relevant to the non-automated bagging of flours (products in which the grains have been ground down to a fine powder or which are naturally fine, e.g. clay powder). The bagging of coarse products is covered by guidance sheet **2.2.30a**.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure that bags and bag filling equipment are fit for purpose. The quality of the bags is crucial to preventing leakage of dust through the bag seams.
- Consideration should be given to screw bag filling, rather than combined rotary impellor/air packing. The screw filling method will reduce the problem of having to remove entrained dusty air from the bags.
- Flour products should be conditioned prior to bag filling. By leaving the flour to settle inside the storage silo, the material will become compacted thus removing entrained air. Conditioning in this way will ensure a more consistent bulk density, facilitating better control of the bagging process.
- When designing hoppers for effective product conditioning, consideration will need to be given to height constraints.
- Ensure that bags are effectively clamped/sealed onto the bagging head during bag filling to prevent the escape of dust.
- Position the bagging head inside a dust extraction hood which is enclosed as much as possible. Refer to task guidance sheet **2.1.13**.
- The dust extraction system serving the hood must have sufficient capture velocity to prevent the escape of any dust emitted through the bag seams and dust discharged from the bagging head when the bag is removed.



- Bags must be sealed shut as soon as they are removed from the bagging head. Bags with self-sealing valves are available or, alternatively, bag stitching techniques may be used.
- Consider mechanical/pneumatic assistance with bag handling.
- When bagging silica flour products, consideration should be given to full or partial automation of the process in order to prevent personal exposure to respirable crystalline silica dust.
- In automated bagging systems, the use of a carousel system enables many bags to be filled simultaneously at a very slow rate using a screw feed. When bags are filled slowly, less dust is emitted.

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer's recommendations.

EXAMINATION AND TESTING

- Visually check the equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of the dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.
- Store bags in a safe place and dispose of empty bags safely.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|---|---|--|---|
| <input type="checkbox"/> Make sure that the bagging machine is working properly. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Even if it is not normally necessary for you to wear a dust mask, it may be necessary for you to wear one temporarily in the event of a spillage or if other control measures fail. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. |
| <input type="checkbox"/> Make sure that bags are free from defects, especially as regards valve construction. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica while the problem persists. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Use handling aids when available. |
| <input type="checkbox"/> Make sure that the dust extraction system is switched on and is working correctly. | | | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on dust control during the filling of small bags with flour products.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.

GOOD PRACTICES FOR AUTOMATED SMALL BAG FILLING


This activity covers bagging operations for small bags (2.5kg-50kg) with dry products containing crystalline silica. This sheet is only relevant to the automated bagging of flours, fines and powder. For automated bagging, “form fill seal” technology allows for effective control of airborne dust generation when bagging powders. The bagging of coarse products is covered by sheet **2.2.30a**, and the non-automated bagging of flours, fines and powder is covered by **2.2.30b**.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Ensure that bags and bag filling equipment are fit for purpose. The quality of the bags is crucial to preventing leakage of dust. It is strongly recommended to use automated bag feeding machines so that human operation is restricted to monitoring, unblocking, maintenance & repair. Placing onto pallets may be automated using a robot palletiser.
- Use long roll of plastic film to produce the bags. The plastic film is formed into a continuous, sealed sock, into which the silica containing material is poured. As such, the process is largely enclosed. The top and bottom of each bag is sealed using a heat sealer.
- Use local exhaust ventilation at all points where airborne dust may be generated.
- Release entrained air in order to allow the bags to be stacked onto pallets. This may be done by lightly compressing the bags after filling. For coarse materials (e.g. sand sized), entrained air is released through micro-perforations in the bags. For fine/flour materials, the use of micro-perforations may not be suitable. In this case, the air may be released through a specially designed seal on each bag, with local exhaust ventilation.
- Get advice from a specialist provider of bagging machinery in order to ensure the machinery, including the local exhaust ventilation system, is designed correctly for the type of material.
- Use bagging equipment designed & manufactured by specialised companies, conforming to the European legislation for Environmental protection, Safety & Health.
- Ensure that bags are effectively attached onto the bagging head during bag filling to prevent the escape of dust.



- Provide properly designed de-dusting systems as integral parts of the bagging machines.
- Bags must be sealed shut as soon as they are removed from the bagging head. Bags with self-sealing valves are available or, alternatively, bag stitching techniques, heat and ultrasonic sealing may be used.
- Consider mechanical/pneumatic assistance with bag handling.
- When bagging silica powder products, consideration should be given to full or partial automation of the process in order to prevent personal exposure to respirable crystalline silica dust.
- In automated bagging systems, the use of a carousel system enables many bags to be filled simultaneously. When bags are filled slowly, less dust is emitted.

MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer’s recommendations.

EXAMINATION AND TESTING

- Visually check the equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of the dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.
- Store bags in a safe place and dispose of empty bags safely.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.

- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3** dedicated to Supervision.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by its suppliers.

EMPLOYEE CHECKLIST

- | | | | |
|---|---|--|---|
| <input type="checkbox"/> Make sure that the bagging machine is working properly. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. | <input type="checkbox"/> Even if it is not normally necessary for you to wear a dust mask, it may be necessary for you to wear one temporarily in the event of a spillage or if other control measures fail. | equipment provided in accordance with instructions. |
| <input type="checkbox"/> Make sure that bags are free from defects, especially as regards valve construction. | <input type="checkbox"/> If you find any problems, tell your supervisor. If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica while the problem persists. | <input type="checkbox"/> Clear up spills straight away. Use vacuum or wet cleaning methods. | <input type="checkbox"/> Use handling aids when available. |
| <input type="checkbox"/> Make sure that the dust extraction system is switched on and is working correctly. | | <input type="checkbox"/> Use, maintain and store any respiratory protective | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on dust control during the filling of small bags with flour, fine and powder products.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.

GOOD PRACTICES FOR TRANSPORT SYSTEMS FOR FINE DRY SILICA PRODUCTS

This activity relates to the design of the transport systems for fine dry silica products.

ACCESS


Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- It is preferable to use enclosed handling systems when transporting silica flour.
- **Pneumatic systems** are appropriate for both horizontal and vertical transport of silica flour.
- For horizontal transport in **pneumatic systems**, pipes should be angled downwards where possible to prevent flour settling in the pipes and causing a blockage in the event system pressure is lost.
- The pipe work in **pneumatic systems** should be designed to minimise unnecessary obstacles and to minimise sharp bends. Pipe connections should be properly sealed.
- For **air slides**, the fluidising air will be drawn away by the dust extraction system. For this reason, air slides cannot be used if the product is too fine. If the surface area is more than 10,000 cm²/g, use screw conveyors. More than one de-dusting connection may be required on long lengths in order to correctly balance airflows.
- **Air slides** should be inclined slightly in order to assist the horizontal transport of silica flour. The quality of the cloth used in air slides should be selected to avoid excessive pressure loss for the fan, whilst also preventing silica flour from falling through the cloth and causing it to become blocked.
- For **screw conveyors**, the screw must be enclosed. Specialist design is required due to the abrasive properties of silica flour (contact an experienced supplier).
- **Screw conveyors** may need to be equipped with dust extraction systems unless they are connected to equipment that already operates under negative pressure. Refer to task guidance sheet **2.1.13**.
- **Conveyor belts are not suitable for the transportation of loose silica flour.** However, they may be used for the transport of other, coarser, materials and in machinery that handles bags of silica flour. Conveyors handling bags of silica flour, or other dusty materials, should be enclosed and equipped with dust extraction.
- **Elevators** are suitable for vertical transport, provided they are fully enclosed. Dust extraction systems may be required unless elevators are connected to equipment that already operates under negative pressure.
- It may be necessary to apply fluidising air at the base of **silos** holding silica flour. Such systems should be designed so that the fluidising air is only applied at times when it is necessary to make the silica flour flow out of the silo. Fluidising air should not be left switched on permanently in situations where the air could migrate and cause silica flour to be emitted under pressure from elsewhere in the system.



GUIDANCE FOR EMPLOYERS ON CONTROLLING EXPOSURE TO RCS IN THE WORKPLACE



MAINTENANCE

- Ensure equipment used in the task is maintained as advised by the supplier/installer in efficient working order and in good repair.
- Replace consumables (filters etc.) in accordance with the manufacturer’s recommendations.

EXAMINATION AND TESTING

- Visually check the equipment at least once per week for signs of damage or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of the dust suppression and/or extraction equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING


- Clean your workplace on a regular basis.
- **DO NOT clean up with a dry brush or using compressed air.**
- Use vacuum or wet cleaning methods.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given on the following page.



PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Provide pictograms on doors to indicate areas where respiratory protective equipment must be worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Provide enough places where Personal protective equipment can be found (e.g. box with disposable dust masks). Indicate those places with pictograms.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Look for signs of damage or wear of building parts and of your work equipment. If you find any problems, tell your supervisor. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Clean up control cabins using vacuum or wet cleaning methods. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Problems with silica flour transportation systems may be indicated by emissions of dust into the workplace air and by the appearance of piles of silica flour on floors and surfaces. Report any of these to your supervisor. | <input type="checkbox"/> Clear up spills straight away. Use vacuum cleaning or wet mopping. Dispose of spills safely. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides advice on the design of transport systems for silica flour products.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR WATER ASSISTED DUST SUPPRESSION

This activity relates to the use of water flooding and of atomised water mists to suppress the generation and lower the concentration of airborne crystalline silica dusts.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- If possible, use water fed tools for cutting, grinding and shaping crystalline silica containing products.
- Consider the application of water sprays or trickles to working surfaces when water fed tools are not available.
- In circumstances where there will be no adverse impact on process conditions, product quality or health and safety, apply water mists in work areas where airborne crystalline silica may be generated by material and product handling.
- Ensure electrical systems have adequate protection when used with water flooding, spraying or misting.
- Take precautions to ensure the control of legionella and other biological agents in water storage and delivery systems.
- Take precautions to ensure that wastewater and sludges are disposed according to appropriate prescriptions.

MAINTENANCE

- Ensure water dust suppression equipment used in the task is maintained as advised by the supplier/installer in efficient working order and good repair.
- Replace consumables in accordance with the manufacturer's recommendations.



EXAMINATION AND TESTING

- Visually check all equipment for signs of damage at least once per week or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use.
- Obtain information on the design performance of dust suppression equipment from the supplier. Keep this information to compare with future test results.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean water dust suppression equipment as instructed by the manufacturer/supplier.
- **Avoid accumulation of slurries/sludges.**
- Ensure spills are cleaned up immediately, and provide adequate spill control equipment.
- **DO NOT allow collected slurries/sludges to dry out and the dust to become airborne.**

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.

- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine areas where personal protective equipment must be used. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean, when not in use.
- Replace personal protective equipment at intervals recommended by the manufacturer/supplier.

EMPLOYEE CHECKLIST

- | | | | |
|---|---|--|---|
| <input type="checkbox"/> Make sure that water dust suppression equipment is working properly. | <input type="checkbox"/> Protect water supplies against freezing. | <input type="checkbox"/> Clean up spills immediately. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> Ensure water supplies are adequate with an uninterrupted supply during use for dust suppression. | <input type="checkbox"/> Look for signs of damage or malfunction, and if you find any tell your supervisor immediately. | <input type="checkbox"/> Clean dust suppression equipment regularly and after use. | |
| | | <input type="checkbox"/> Keep personal protective equipment clean and properly stored. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this sheet provides good practice advice on dust control by using water flooding and atomised water mists.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Document on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica dust in the workplace.

GOOD PRACTICES FOR INSTALLATION OF COUNTERTOPS

This task guidance sheet provides good practice guidance for work procedures, personal protective equipment and equipment dedicated to significantly reducing the level of respirable crystalline silica when cutting, grinding or polishing stone surfaces (e.g., engineered stone, natural stone or porcelain) at the installation site (e.g., consumer's home). These guidelines protect both the installer and anyone else in the area.

ACCESS

Restrict access to the work area to authorised personnel only.

GENERAL

- If no cutting, grinding, sanding or polishing of the countertops is performed during installation, no respirable crystalline silica should be released.

PRE-INSTALLATION

- Prepare all slabs in your plant, not at the installation site.
- Clean dust off the front and back of slabs before transporting them to the installation site.
- If significant cutting is required upon installation, return the slabs to the plant for re-cutting.
- Shut down and seal off the local heating/air-conditioning system.

TOOLS ON SITE


- If performing modifications at the installation site is unavoidable, work outdoors using water-integrated tools.
- If an outdoors area is not available, work indoors using tools with a dust collector connected to a vacuum cleaner with HEPA filter.

POST-INSTALLATION

- After installation clean the workplace using wet methods or HEPA filtered vacuum cleaner.

EXAMINATION AND TESTING

- Visually check the equipment and water supply for signs of damage before every use.
- Make sure that the equipment and water supply operates correctly.



- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Remove dust in sealed sacks according to local regulations.
- Clean the equipment regularly according to the recommendations of the manufacturer.
- Clean slabs and floor with low pressure wet hosing or wet sweeping.
- Clean dry spillage with HEPA vacuum cleaning systems.
- **DO NOT clean up with a dry brush or using compressed air.**

TRAINING

- Give your employees information regarding the health effects associated with respirable crystalline silica.
- Provide employees with training on dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided; and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the procedures in the checklist below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to personal protective equipment and to task guidance sheet **2.2.37** dedicated to respiratory protective equipment for the slab industry.
- Water-integrated rotating tools generate respirable crystalline silica-contaminated water mist, which may be dispersed and inhaled. For this reason, respiratory protective equipment may be necessary even when using water-integrated tools.
- Indicate areas where personal protective equipment must be worn.
- Use a half face respirator with P3 filter when fabricating with wet manual tools or tools with a dust collector connected to a vacuum cleaner with HEPA filter at the installation site.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by the supplier.

EMPLOYEE CHECKLIST

- | | | | |
|---|--|--|---|
| <input type="checkbox"/> Fabricate all slabs in your plant. If significant cutting is required upon installation, return the slabs to the plant for re-cutting. | <input type="checkbox"/> Don't use dry tools! Dry fabrication generates very high levels of respirable crystalline silica. | <input type="checkbox"/> Use a half face respirator when performing any cutting, grinding, sanding, drilling or polishing of countertops at the installation site. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. |
| <input type="checkbox"/> Make sure the installation site is well ventilated. | <input type="checkbox"/> Clean up spills straight away. Use vacuum or wet cleaning methods. Dispose of spills immediately. | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| <input type="checkbox"/> At the installation site use wet manual tools or tools with a dust collector connected to a vacuum cleaner with HEPA filter. | | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.

GOOD PRACTICES FOR RESPIRATORY PROTECTIVE EQUIPMENT FOR THE SLAB INDUSTRY

This task guidance sheet provides good examples use of respiratory protective equipment (RPE) in a case by case approach in all parts of typical fabrication plants of slabs, installation sites and related work areas to increase worker protection from respirable crystalline silica.

ACCESS

Restrict access to the work area to authorised personnel only.

GENERAL

- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Choose the appropriate respiratory protective equipment according to the respirable crystalline silica level, in consultation with an occupational health and safety professional, and considerations in the “When to use” sections below.
- When it is necessary to use more than one item of PPE, make sure that these items are compatible with each other.
- Use respiratory protective equipment according to the supplier’s instructions.
- Keep records of use, training and maintenance.
- Use a properly fitting respirator (half face or disposable mask) that creates a tight seal.
- Perform a medical/occupational health assesment to ensure that fabricators are able to work with respiratory protective equipment.

Using respiratory protective equipment does not exempt the employer from controlling the level of respirable crystalline silica or from bringing it to below the required Occupational Exposure Limit.



GUIDANCE FOR EMPLOYERS ON CONTROLLING EXPOSURE TO RCS IN THE WORKPLACE



WHEN TO USE A HALF FACE RESPIRATOR

- When fabricating with wet manual tools in the fabrication plant.
- When standing close to locations where respirable crystalline silica is created.
- At the installation site if performing dust-producing modifications.



WHEN TO USE POWERED AIR PURIFYING RESPIRATORS (PAPR)

- If the fabricator has facial hair
- If the protection achieved with any other respiratory protective equipment is not sufficient
- If exposure levels are thought to be very high

In these cases, use a PAPR type TH3 equipped with a P3 filter. Always consult your personal protective equipment supplier in order to make sure that the protection factor is adequate.



WHEN TO USE A DISPOSABLE MASK

- Only in the case of short or occasional exposures to respirable crystalline silica (workers and visitors), e.g.:
 - when washing the floor and machinery with running water
 - near CNC machines that are water-connected to exhaust ventilation systems
- Masks marked with the letters NR (not reusable) are intended for single shift use. Masks marked with the letter R (reusable) are intended for more than single shift use, according to the supplier's instructions.
- Ensure that your disposable dust mask contains documentation that it conforms to standard EN 149:2001.



EXAMINATION AND TESTING

- For each work activity, make an assessment to determine how frequently respiratory protective equipment should be replaced in order to guarantee its effectiveness, as advised by the supplier.
- Visually check respiratory protective equipment daily for signs of damage. If used infrequently, check it before each use.
- Seek advice from the supplier on appropriate fit testing methods.
- Perform fit testing before first use to ensure that it creates a good seal and provides the required protection. This can be done using simple testing methods, e.g., a mist of sugar solution can be dispersed in the air to check if the operator tastes it. If so, there is evidence of leakage.
- Check effectiveness each time it is worn.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).

CLEANING AND HOUSEKEEPING

- Keep non-disposable items of respiratory protective equipment clean.
- Employers must provide clean storage facilities for respiratory protective equipment when not in use.
- Use wet cleaning methods.
- **Respiratory protective equipment should NOT be taken home.**
- **DO NOT clean up with a dry brush or using compressed air.**

MAINTENANCE

- Ensure equipment used in the task is maintained in efficient working order and in good repair as advised by the supplier.
- Replace respiratory protective equipment at intervals recommended by the supplier.

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given on the following page.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to personal protective equipment.
- Respiratory protective equipment should be selected that is compatible with other items of personal protective equipment, e.g., ear protection, goggles, welding visors.

EMPLOYEE CHECKLIST

- Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor.
- Make sure to use the right respiratory protective equipment for each task.
- Even if you do not normally wear respiratory protective equipment, it may be necessary for you to wear it temporarily in the event other control measures fail.
- Use, maintain and store any respiratory protective equipment provided in accordance with instructions.
- Adjust your respiratory protective equipment so that it fits you correctly.
- If you have facial hair, this could reduce the effectiveness of a dust mask. In this case you should use PAPR.
- When it is necessary for you to wear more than one item of personal protective equipment, ensure that all items are compatible with each other.

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica. Specifically, this task guidance sheet provides good examples of how one specific sector chooses the type of mask appropriate for the task.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, the examples given here may not be relevant for the other sectors. Seek advice from an occupational health

professional to adapt to another sector.

This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.

GOOD PRACTICES FOR MANUFACTURING OF STONE BY FABRICATORS: WATER-INTEGRATED MACHINERY TOOLS AT THE FABRICATION PLANT

This task guidance sheet provides good practice guidance for processing (e.g., cutting, grinding and shaping) slabs containing crystalline silica using water-integrated CNC (Computer Numerical Control) machines, manual saw and manual tools. Use of this equipment significantly reduces the level of respirable crystalline silica.

ACCESS


Restrict access to the work area to authorised personnel only.

GENERAL

- Dry cutting, grinding or polishing stone surfaces (e.g., engineered stone, natural stone or porcelain) generate very high respirable crystalline silica levels. Properly designed water-integrated tools and machinery significantly reduce the level of respirable crystalline silica and should therefore be used for all fabrication processes.
- It is also advisable to use water curtains as a measure to reduce or eliminate the dust.

CNC MACHINES

- CNC (Computer Numerical Control) machining, is a manufacturing process in which pre-programmed computer software dictates the movement of factory tools and machinery. These machines are used for automatic initial cutting of slabs.
- Use CNC machines such as waterjet cutters and automated sawing machines.
- Keep CNC safety doors closed to prevent dust dispersal and to distance the operator from the dust source.



GUIDANCE FOR EMPLOYERS ON CONTROLLING EXPOSURE TO RCS IN THE WORKPLACE

MANUAL TOOLS

These tools are used for manual fabrication processes (e.g., drilling, cutting and polishing slabs) after initial cutting. When working with manual tools the fabricator is very close to the dust source. Therefore:

- Use only water-integrated manual tools. If it is not possible to use water-integrated tools at the installation site, follow the instructions in task guidance sheet **2.2.36**, Installation of Countertops.
- Control water spray using guards or plastic flaps.
- Set air and water pressure to achieve minimum dust generation.
- Use a half face respirator with P3 filter.

MANUAL SAWS

Even when equipped with water integration, manual saws used for automatic initial cutting of slabs (e.g., bridge saws) are less recommended because:

- the operator is close to the dust source.
- there are no safety doors.
- they are less accurate and slower than CNCs.
- worker exposure to respirable crystalline silica is generally higher than with CNCs.

When working with manual saws always use a half face respirator with P3 filter.

EXAMINATION AND TESTING

- Visually check the equipment and water supply for signs of damage before every use.
- Make sure that the equipment and water supply operates correctly.
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given on the following page.



CLEANING AND HOUSEKEEPING

- Clean the equipment regularly according to the recommendations of the manufacturer.
- Clean slabs, floor and equipment (e.g., CNCs or manual saw) with low pressure wet hosing or wet sweeping.
- Change the water regularly if you have a closed water system (e.g., at the end of the day).
- Clean dry spillage with HEPA vacuum cleaning systems.
- **Do not clean up with a dry brush or using compressed air.**



GUIDANCE FOR EMPLOYERS ON CONTROLLING EXPOSURE TO RCS IN THE WORKPLACE

TRAINING

- Give your employees information regarding the health effects associated with respirable crystalline silica.
- Provide employees with training on dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided; and what to do if something goes wrong. Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to personal protective equipment and to task guidance sheet **2.2.37** dedicated to Respiratory protective equipment for the slab industry.
- Water-integrated rotating tools generate respirable crystalline silica-contaminated water mist, which may be dispersed and inhaled. For this reason, respiratory protective equipment may be necessary even when using water-integrated tools.

- Indicate areas where personal protective equipment must be worn.
- Use disposable masks with P3 filters near CNC machines that are water-connected to exhaust ventilation systems, or half face respirators with P3 filters when fabricating with manual saws and wet manual tools in the fabrication plant or at the installation site.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean when not in use.
- Replace respiratory protective equipment at intervals recommended by the supplier.

EMPLOYEE CHECKLIST

- | | | | |
|---|--|---|--|
| <input type="checkbox"/> Make sure the room is well ventilated and any water system is switched on and working. | <input type="checkbox"/> Don't use dry tools! Dry fabrication generates very high levels of respirable crystalline silica. | <input type="checkbox"/> If you think there is a problem with your water system, ensure additional control measures are taken to reduce exposure to respirable crystalline silica while the problem persists. | <input type="checkbox"/> Use appropriate respiratory protective equipment even when using wet machinery and tools. |
| <input type="checkbox"/> Use water-integrated machinery and tools to reduce the level of respirable crystalline silica. | <input type="checkbox"/> Clean up spills straight away. Use vacuum or wet cleaning methods. Dispose of spills immediately. | <input type="checkbox"/> Use, maintain and store any respiratory protective equipment provided in accordance with instructions. | <input type="checkbox"/> Check and implement the measures of controlling the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated |
| | <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.

GOOD PRACTICES FOR WET CUTTING PROCESSES OF MASONRY UNITS STONES MATERIALS

This activity relates to fully and semi-automated wet cutting processes of calcium silicate units containing crystalline silica.

ACCESS

Restrict access to the work area to authorised personnel only.

DESIGN AND EQUIPMENT

- Encapsulate the sawing line as much as possible.
- Make the enclosure deep enough to contain equipment and materials.
- Divide each encapsulation into sections to allow easy access for cleaning and maintenance.
- Machine controls should be located well away from sources of airborne dust generation.
- Work only with a connected water system as recommended.
- Ensure that water supplies are adequate and that they are maintained. Take precautions during cold weather against freezing.
- Ensure that all settings of the equipment and water supply are made in accordance with the instruction manual.
- The provision of appropriate drainage systems is essential.



MAINTENANCE

- Ensure equipment used in the task and building are maintained as advised by the supplier/installer in efficient working order and in good repair.

EXAMINATION AND TESTING

- Visually check all equipment for signs of damage at least once per month or, if it is in constant use, check it more frequently. If used infrequently, then check it before each use!
- Keep records of inspections for a suitable period of time which complies with national laws (minimum five years).
- Put in place measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated.

CLEANING AND HOUSEKEEPING

- Clean your workplace on a regular basis.
- Use vacuum or wet cleaning methods.
- **DO NOT clean up with a dry brush or using compressed air.**

TRAINING

- Give your employees information on the health effects associated with respirable crystalline silica dust.
- Provide employees with training on: dust exposure prevention; checking controls are working and using them; when and how to use any respiratory protective equipment provided and what to do if something goes wrong.
- Refer to task guidance sheet **2.3.4** and part 1 of the Good Practice Guide.

SUPERVISION

- Have a system to check that control measures are in place and that they are being followed. Refer to task guidance sheet **2.3.3**.
- Employers should make sure that employees have all the means to perform the checklist given below.

PERSONAL PROTECTIVE EQUIPMENT

- Refer to task guidance sheet **2.1.15** dedicated to Personal Protective Equipment.
- Risk assessment must be carried out to determine whether existing controls are adequate. If necessary, respiratory protective equipment (with the appropriate protection factor) should be provided and worn.
- Provide storage facilities to keep personal protective equipment clean, when not in use.
- Replace the respiratory masks at intervals recommended by the manufacturer/supplier.

EMPLOYEE CHECKLIST

- | | | | |
|--|--|---|---|
| <input type="checkbox"/> Look for signs of damage, wear or poor operation of any equipment used. If you find any problems, tell your supervisor. | <input type="checkbox"/> If you think there is a problem with your dust control equipment, ensure additional control measures are taken to reduce exposure to respirable crystalline silica dust while the problem persists. | <input type="checkbox"/> Do not clean up with a dry brush or using compressed air. | <input type="checkbox"/> Check and implement the measures to control the risk of bacterial growth within water sources used across site, focusing most on systems where water droplets will be generated. |
| | | <input type="checkbox"/> Use, maintain and store any respirator masks provided in accordance with instructions. | |

This guidance sheet is aimed at employers to help them comply with the requirements of workplace health and safety legislation, by controlling exposure to respirable crystalline silica.

Following the key points of this task guidance sheet will help reduce exposure.

Depending on the specific circumstances of each case, it may not be necessary to apply all of the control measures identified in this sheet in order to minimise exposure

to respirable crystalline silica. i.e. to apply appropriate protection and prevention measures. This document should also be made available to persons who may be exposed to respirable crystalline silica in the workplace, in order that they may make the best use of the control measures which are implemented.

This sheet forms part of the Good Practices Guide on silica dust prevention, which is aimed specifically at the control of personal exposure to respirable crystalline silica in the workplace.